

5.2 WNTe Limits for Gaseous and Particulate Exhaust Emissions

5.2.1 Exhaust emissions from an engine shall not exceed the applicable WNTe emission limits when the engine is operated under the specified engine speed and load points defined by the WNTe Control Area in section 7. These emission limits apply to engine use under the ambient conditions specified in section 6. The emissions are determined in accordance with the measurement procedures specified in section 7.

5.2.2 For the purposes of section 5.2.1, the applicable WNTe emission limits expressed in g/kWh for an engine are defined, as follows:

WNTe Emission Limit = WHTC Emission Limit + WNTe Component (or Constituent)

where

“WHTC Emission Limit” is the emission limit (EL) to which the engine is certified pursuant to the WHTC test procedures expressed in g/kWh; and

“WNTe Component” is determined by equations 1 to 4 in section 5.2.3

5.2.3 The applicable WNTe Components expressed in g/kWh shall be determined using the following equations:

for NO _x :	$WNTe\ Component = - 0.02 * EL^2 + 0.3 * EL + 0.09$	(1)
for HC:	$WNTe\ Component = 0.15 * EL^2 + 0.1$	(2)
for CO:	$WNTe\ Component = 0.02 * EL^2 + 0.1 * EL + 0.2$	(3)
for PM:	$WNTe\ Component = 1.3 * EL^2 + 0.1 * EL + 0.004$	(4)

The WNTe Component shall be rounded to the number of places to the right of the decimal point indicated by the applicable emission limit, in accordance with ASTM E 29-04.

Examples of WNTe Components for current emission limits are shown in Annex I.

Annex I

Example of WNTe Limits for Selected Limit Values

Pollutant	Emission Limit [g/kWh]	WNTe Component [g/kWh]	WNTe Limit [g/kWh]
NOx	3.5	0.9	4.4
	2.0	0.6	2.6
	1.5	0.5	2.0
	0.70	0.29	0.99
	0.40	0.21	0.61
	0.30	0.18	0.48
PM	0.13	0.04	0.17
	0.10	0.03	0.13
	0.07	0.02	0.09
	0.03	0.01	0.04
	0.02	0.01	0.03
	0.01	0.01	0.02
HC	0.78	0.19	0.97
	0.55	0.15	0.70
	0.46	0.13	0.59
	0.25	0.11	0.36
	0.19	0.11	0.30
	0.16	0.10	0.26
CO	20.8	10.9	31.7
	5.5	1.4	6.9
	4.0	1.0	5.0
	3.0	0.7	3.7
	2.2	0.5	2.7
	1.5	0.4	1.9