

Japan Research Activities in the GTR-7 Phase 2 amendment Bio RID II Smaller Design Torso Angle seat seating trial

JASIC/Japan

May. 17. 2010






Background of Design Torso Angle Proposal

Note: presented in HR-6-13

Range of design torso angles used in different vehicle types



- Design torso angle is specified by typical driving posture for each type of vehicle and seating height. It is varied from 10° to 30°.
 - For certain seat designs, 25° bears no relation to the real world seating position and in some cases may not even be physically achievable
 - Advise the use of the procedure specified in ECE17 Annex 3
- All other safety tests, including vehicle crash tests, are conducted with the design torso angle.




Smaller Design Torso Angle seat seating trial

Problem in the case of 10 degree torso angle seat

- •Head can not remain laterally level.
- •Distance between head and head restraint is greater than HRMD backset+15mm =112mm.



Develop a new comb to adjust spine for upright torso angle.



Upright tool Standard tool³

Smaller Design Torso Angle seat seating trial



Standard tool







the spine adjusted by original tool


Upright tool

The spine and jacket are able to install without any conflict.










the spine adjusted by new tool for low torso angle


Smaller Design Torso Angle seat seating trial







Spine Pin and Point Measurement Result





Seating Trial Result

- •Dummy head angle and backset are improved with upright tool.
- •In the case of about 14 degree torso angle, head can maintain laterally level, however, backset is little bit smaller than target, 112mm.

Standard tool

with 10 degree torso angle


Upright tool


with 10 degree torso angle

Upright tool

with about 14 degree torso angle condition







SUMMARY




- ◆ The spine and jacket are able to install without any conflict.
- ◆ T2 angle of Upright tool is about 15 degree greater than standard tool
- ◆ Large forward inclination is occurred due to the jacket attachment bolts restriction
- Dummy head angle and backset is improved for 10 degree torso angle seat with upright tool, However, head angle is still tilted due to jacket restriction.
- ◆ In the case of about 14 degree torso angle, head can maintain laterally level, however, backset is 16mm smaller than target value.


DISCUTION



- The upright tool human scientific background and target dimension, including seating backset, are need to verify.
- Jacket and calibration tool modification are need to study.
- Development & research schedule is also need to study. If necessary tentative alternative solution need to study, for example static backset option etc.









Thank you for your attention!

